# **5** Simplex

**ULC** Listed

### **Multi-Application Peripherals**

IDNet<sup>™</sup> Communicating Devices Addressable Manual Stations

#### **Features**

## Individually addressable manual fire alarm stations with:

- Power and data supplied via IDNet addressable communications using a single wire pair\*
- Operation that complies with ADA requirements
- Pull lever that protrudes when alarmed
- Break-rod supplied (use is optional)

#### Multiple models are available:

- Single action operation
- Double action operation, Breakglass or Push
- Two stage pull station

#### For use with Simplex IDNet communications

#### Compact, sealed construction:

- Allows mounting in standard electrical boxes (with spacer)
- Screw terminals for wiring connections
- · Reduces dust infiltration

**Tamper resistant reset key lock** (keyed same as Simplex fire alarm cabinets)

#### **Multiple mounting options:**

- Surface or semi-flush with standard or matching Simplex boxes
- Flush mount adapter available
- Adapters are available for retrofitting of existing addressable stations

#### Description

The Simplex 4099 Series addressable stations combine the familiar Simplex manual station housing with a compact communication module that is easily installed to satisfy demanding applications. Its integral individual addressable module (IAM) constantly monitors status and communicates changes to the connected control panel via Simplex IDNet communications wiring.

\* Simplex IDNet addressable communications are protected by U.S. Patent 4,796,025.





4099-9001 Single Stage

4099-9xxx Two Stage





4099-9002 Breakglass

4099-9003 Push

#### Operation

**Activation** of the Simplex 4099-9001 single manual station requires a firm downward pull to activate the alarm switch. Completing the action breaks an internal plastic break-rod (visible below the pull lever, use is optional). The use of a break rod can be a deterrent to vandalism without interfering with the minimum pull requirements needed for easy activation. The pull lever latches into the alarm position and remains extended out of the housing to provide a visible indication.

**Double Action Stations (Breakglass)** require the operator to strike the front mounted hammer to break the glass and expose the recessed pull lever. The pull lever then operates as a single action station.

**Double Action Stations (Push Type)** require that a spring loaded interference plate (marked PUSH) be pushed back to access the pull lever of the single action station.

**Station reset** requires the use of a key to reset the manual station lever and deactivate the alarm switch. (If the break-rod is used, it must be replaced.)

**Station testing** is performed by physical activation of the pull lever. Electrical testing can be also performed by unlocking the station housing to activate the alarm switch.

#### **IDNet Addressable Manual Station Product Selection**

#### **Addressable Manual Stations**


Model	Description	Mounting Options
4099-9001	Single action addressable manual station	
4099-9002	Double action addressable manual station, Breakglass operation	
4099-9003	Double action addressable manual station, Push operation	
4099-9004CA	Two-stage addressable manual station	
4099-9005CA	Two-stage addressable manual station with N/C Contact	
4099-9006CA	Two-stage addressable manual station, Breakglass operation	
4099-9007CA	Two-stage addressable manual station, Breakglass operation with N/C Contact	
4099-9008CA	Single action addressable manual station with N/C Contact	
4099-9009CA	Single action addressable manual station, Breakglass operation with N/C Con	ntact

Models shown are English Language.
For 4099-9001 add 'CF' for French, 'CB' for Bilingual
e.g. 4099-9001, 4099-9001CF, 4099-9001CB.
For all other models add 'F' for French, 'B' for Bilingual e.g. 4099-9004CA, 4099-9004CAF, 4099-9004CAB

#### **Mounting Accessories**

Model	Description	Reference	
2975-9178	Surface mount steel box, red	Defends none O for disconnique	
2975-9022	Cast aluminum surface mount box, red	Refer to page 3 for dimensions	
2099-9810CA	Semi-flush trim plate for single gang box, red	Primarily for retrofit, refer to	
2099-9814	Surface trim plate for Wiremold 5744-2, red	page 4	
2099-9819	Flush mount adapter kit, black	Defends a see Afendale	
2099-9820	Flush mount adapter kit, beige	Refer to page 4 for details	
2099-9803	Replacement breakglass		
2099-9804	Replacement break-rod		

Specifications		
Power and Communications	IDNet, 1 address per station, up to 2500 ft (762 m) from fire alarm control panel, up to 10,000 ft (3048 m) total wiring distance (including T-Taps)	
Address means	Dipswitch, 8 position	
Wire Connections	Screw terminal for in/out wiring, for #18 to #14 AWG wire	
UL Listed Temperature Range	32° F to 120° F (0° C to 49° C) intended for indoor operation	
Humidity Range	Up to 93% RH at 100° F (38° C)	
Housing Colour	Red with white raised lettering	
Material	Housing and pull lever are Lexan® polycarbonate	
Pull Lever Colour	White with red raised lettering	
Housing Dimensions	5" H x 3 3/4" W x 1" D (127 mm x 95 mm x 25 mm)	



#### **Application Reference**

Refer to N.B.C. 3.2.4.12 for requirements on manual pull stations.

Refer to CAN/ULC-S524, Section 5-2 for the requirements on the installation of manual pull stations.

#### IDNet Manual Station Mounting for 4099-9004, -9005, -9006, -9007, -9008, -9009

Simplex, the Simplex logo, and IDNet are either trademarks or registered trademarks of Simplex Time Recorder Co. in the U.S. and/or other countries. NFPA 72 and National Fire Alarm Code are registered trademarks of the National Fire Protection Association (NFPA). Lexan is a registered trademark of the General Electric Co.

